

БЗК исп.02

XT1

1	+ U _{in}	—
2	+ U _{in}	—
3	0 V	—
4	0 V	—

XT2

Out 1	1
0V	2

XT3

Out 2	1
0V	2

XT4

Out 3	1
0V	2

XT5

Out4	1
0V	2

XT6

Out5	1
0V	2

XT7

Out6	1
0V	2

XT8

Out7	1
0V	2

XT9

Out8	1
0V	2